



BRUTE LosiderSafe Instruction Sheet



FASTENERS INCLUDED

<u>QTY</u>	<u>DESCRIPTION</u>
6	5/16 x 1 Hex Bolts
8	5/16 Flat Washers
2	5/16 Locknuts
2	1/4 x 3 J Bolts
2	1/4 HEX Nuts
2	1/4 Lock Washers
2	Fender Washers

Note: The following is a general installation guideline for most trucks. The LosiderSafe size and your desired mounting location will vary with each installation..

CUSTOMER SERVICE 800-239-2343
www.uniquetruckaccessories.com

DATE: 4/2020

PROCEDURE

1. Place 1 1/2" foam tape under the rail ledge of the toolbox. This will help prevent scratching and promote sealing.
2. Preassemble each upper & lower support legs using a 5/16 x 1 bolt, flat washers, and locknut. Leave bolt slightly loose.
3. Measure the distance from the top of the truck bed rail to the bottom of the truck bed. Subtract 11" from this measurement and that is the fixed dimension for the support leg. Tighten bolt.
4. Turn the box upside down and fasten each support leg to the bottom using the factory installed plushnuts and two 5/16 x 1 bolts/flat washers
5. Set box on truck in desired location. The now fixed support legs allow the box to set on the bed-rail.
6. Install the J Bolts. See Drawing "A". Drill one 5/16 hole through the box rail and secure 1/4" J bolt under the rail using 1/4" fender washers, lock washers, and nuts.

Final Height Adjustments can be made by adjusting the support leg up or down.

Note: Under extreme environments you may fasten the support leg to the floor of the truck. This is not necessary for standard installations.

Finished Installation

