



**8 FASTENERS FROM MOUNTING CHANNEL
TO UNDERBODY & BACKPACK**

**Fasten 4– 5/16x1 bolts/nuts/ 8-
flat washers through the under-
body toolbox. All four bolts will
fasten through the horizontal an-
gle welded inside the underbody
and through the plates welded in-
side the backpack.**

**Fasten the mounting channel un-
derneath the backpack and un-
derbody with 8– 5/16x1 bolts/
nuts/ 16– flat washers.**

See Diagram

FASTENERS SUPPLIED

12– 5/16 X 1 HEX BOLTS

12– 5/16 NYLOCK NUTS

24– 5/16 FLAT WASHERS